

INSTRUCTIONS FOR SET UP OF SELFIE STATION

*REMOVE HALO RING WITH ATTACHED IPAD AND SET ASIDE.

*REMOVE TWO LONG PIECES OF PROTECTIVE FOAM LABELED FOAM 1 AND FOAM 2 AND SET ASIDE.

*REMOVE 3 PRONGED LEGS FROM CASE.

*PULL “UNLOCK” CIRCLE TAB TO RELEASE LEGS. ROTATE LEGS TO BE EQUIDISTANT LIKE A 3-LEGGED STOOL. RELEASE “UNLOCK” CIRCLE TAB TO SECURE LEGS IN PLACE.

* REMOVE SMALL PIECE OF FOAM LABELED FOAM 3 OVER END OF EXTENDER POLE AND SET FOAM ASIDE.

*REMOVE EXTENDER POLE FROM CASE.

*INSERT EXTENDER POLE INTO LEGS AND TIGHTEN BOTTOM KNOB. **DO NOT OVERTIGHTEN.**



*EXTEND POLE TO DESIRED HEIGHT THEN TIGHTEN KNOB TO SECURE POLE HEIGHT. **DO NOT OVERTIGHTEN.**

*REMOVE SMALLER METAL ATTACHMENT FROM CASE AND ALINE TOP OF POLE INTO THE DOUBLE-CLAMP SECTION. BEFORE TIGHENING LARGE KNOB, MAKE SURE THE HOLE ON THE OTHER SECTION IS PARALLEL WITH THE FLOOR.



*REMOVE ELECTRIC CORD FROM CASE AND PLUG INTO THE BOTTOM OF HALO RING.

*INSERT METAL PIECE ON THE BACK OF HALO RING ALL THE WAY INTO THE HOLE AND TIGHTEN SECURELY BUT BE CAREFUL TO NOT OVERTIGHTEN.



*REMOVE SURGE PROTECTOR FROM CASE. PLUG ELECTRIC CORD INTO THE SURGE PROTECTOR. PLUG THE SURGE PROTECTOR INTO A WALL OUTLET.

*TURN SMALL DIAL ON RIGHT SIDE OF IPAD TO TURN ON AND ADJUST BRIGHTNESS TO DESIRED LEVEL.