

INSTRUCTIONS FOR TAKE DOWN ON SELFIE STATION

* TURN SMALL DIAL ON RIGHT SIDE OF IPAD UNTIL IT CLICKS AND TURNS OFF HALO LIGHT.

*UNPLUG SURGE PROTECTOR FROM WALL OUTLET.

*CAREFULLY GRASP HALO RING AND LOOSEN SMALL KNOB ON THE METAL ATTACHMENT. SLIDE HALO STRAIGHT OUT AND SET ASIDE.

*LOOSEN LARGE KNOB ON METAL ATTACHMENT AND LIFT UP TO REMOVE. PLACE IN CASE.



*LOOSEN KNOB MIDDLE WAY DOWN EXTENDER POLE. SLIDE INTO LOWER POLE. LOOSEN KNOB AT BOTTOM OF POLE AND REMOVE EXTENDER POLE. PLACE IN CASE AND PLACE FOAM 3 OVER END OF POLE.

*PULL “UNLOCK” CIRCLE TAB TO RELEASE LEGS. ROTATE LEGS IN SAME DIRECTION THEN RELEASE CIRCLE TAB TO SECURE. PLACE IN CASE.

*PLACE FOAM 1 AND FOAM 2 IN CASE.

*UNPLUG CORD FROM HALO RING. PLACE CORD AND SURGE PROTECTOR NEXT TO THE METAL ATTACHMENT IN CASE.

*PLACE HALO RING WITH ATTACHED IPAD IN CASE ON TOP OF FOAM 1 AND FOAM 2. MAKE SURE THE HOME BUTTON IS TOWARD THE BOTTOM OF THE CASE TO ENSURE PROPER STORAGE.

*CLOSE AND LATCH CASE.